




ST1 SOFT TRIFOLD TONNEAU COVER




Scan QR code
to watch video
installation guide




blackseriesauto.com


WARNING



Prior to vehicle operation, all four clamps must be secured in the closed position.




Alternatively, both safety buckles must be fastened to the front frame clips. Ensure clamps are secured in the open folded position.




DO NOT drive with the cover in a partially open position.

Black Series is not responsible for damage arising from failure to follow instructions relating to the product's use.




Periodically check the clamps to ensure they are secured to prevent possible operational failures.


What's In The Box




1x Soft Trifold Tonneau Cover



1x Spare Clamp




1x Weatherstrip Seal




For Toyota

4x Clamp Brackets




1x Hex Key

Tonneau Cover Installation




Apply weatherstrip seal if your truck's front bed rail (bulkhead) is lower than the side bed rails.

Ensure the surface is clean prior to applying seal.



Place the cover on the front end of the bed and center it.

Secure the front clamps.




For all clamps:

1. Unclip the clamp from its storage position.
2. Slide the handle lever to the edge of the truck bed rail.
3. Adjust to proper tension/height by rotating the clamp.




To adjust clamp tension/height:



Rotate clamp counterclockwise to tighten.




Rotate clamp clockwise to loosen.



4. Pivot the lever from vertical to horizontal position.
5. Hook the latch under the bed rail lip/flange.
6. Push handle down to lock and secure clamp.




Do not overtighten or forcefully clamp the latch. Otherwise, the clamp rod may bend.




For Toyota

1. Slide the clamp brackets into the utility track system.
2. Position each clamp bracket underneath a clamp.



3. Secure each clamp bracket with a hex key.
4. Attach clamps onto the clamp bracket. See Step 3A.

4




Unbuckle the safety clips and unfold the cover towards the tailgate.

Secure rear clamps. Repeat Step 3A.

Shut the tailgate.

Reposition the cover and readjust the clamps if necessary.

5



To use the cover in the open, folded position:

1. Release the rear clamps.
2. Stow and clip / tuck the clamps in storage position.
3. Fold the cover forward.
4. Fasten both safety buckles to the front frame clips.

Black Series One (1) Year Limited Warranty

For Black Series Branded Product Only

IMPORTANT: BY USING YOUR BLACK SERIES PRODUCTS YOU ARE AGREEING TO BE BOUND BY THE TERMS OF THE BLACK SERIES ONE (1) YEAR LIMITED WARRANTY ("WARRANTY") AS SET OUT BELOW.

DO NOT USE YOUR PRODUCT UNTIL YOU HAVE READ THE TERMS OF THE WARRANTY. IF YOU DO NOT AGREE TO THE TERMS OF THE WARRANTY, DO NOT USE THE PRODUCT AND RETURN IT WITHIN THE RETURN PERIOD STATED IN BLACK SERIES' OR RETAILER'S RETURN POLICY WHERE YOU PURCHASED IT FOR A REFUND.

WHAT IS COVERED BY THIS WARRANTY?

Black Series warrants the Black Series branded hardware products and the Black Series branded accessories contained in the original packaging ("Black Series Product") against defects in materials and workmanship when used normally in accordance with Black Series' published guidelines for a period of ONE (1) YEAR from the date of original retail purchase by the end-user purchaser ("Warranty Period"). Black Series' published guidelines include but are not limited to information contained in technical specifications, user manuals and service communications. Warranty is non-transferable. Proof of purchase is required.

WHAT IS NOT COVERED BY THIS WARRANTY?

Black Series is not responsible for damage arising from failure to follow instructions relating to the Black Series' Product use.

This Warranty does not apply:

- (a) to consumable parts, such as rubber seals or protective coatings that are designed to diminish over time, unless failure has occurred due to a defect in materials or workmanship;
- (b) to cosmetic damage, including but not limited to scratches, dents and broken plastic unless failure has occurred due to a defect in materials or workmanship;
- (c) to damage caused by use with a third party products or accessories or components; (d) to damage caused by accident, abuse, misuse, fire, liquid contact, earthquake or other external cause; (e) to damage caused by operating the Black Series Product outside Black Series' published guidelines;
- (f) to damage caused by service performed by anyone who is not a representative of Black Series or a Black Series service provider;
- (g) to a Black Series Product that has been modified to alter functionality or capability without the written permission of Black Series;
- (h) to defects caused by normal wear and tear or otherwise due to the normal aging of the Black Series Product;
- (i) if any serial number or SKU has been removed or defaced from the Black Series Product; or
- (j) to damage caused by improper service or installation or removal of Black Series Product.

WHAT WILL BLACK SERIES DO IN THE EVENT THE WARRANTY IS BREACHED?

If during the Warranty Period you submit a claim to Black Series in accordance with this warranty, Black Series, will, at its option:

- (i) repair the Black Series Product using new or previously used parts that are equivalent to new in performance and reliability,
- (ii) replace the Black Series Product with the same model (or with your consent a product that has similar functionality) formed from new and/or previously used parts that are equivalent to new in performance and reliability, or
- (iii) exchange the Black Series Product for a refund of your purchase price.

Black Series may request that you replace certain user-installed parts or Black Series Products. A replacement part or Black Series Product, including a user-installable part that has been installed in accordance with instructions provided by Black Series, assumes the remaining term of the Warranty or ninety (90) days from the date of replacement or repair, whichever provides longer coverage for you.

HOW TO OBTAIN WARRANTY SERVICE?

Please contact a Black Series representative at blackseriesauto.com. A Black Series representative will help determine whether your Black Series Product requires service and, if it does, will inform you how Black Series will provide it.

WARRANTY SERVICE OPTIONS

Black Series will provide warranty service through one or more of the following options:

- (i) Carry-in service. You may return your Black Series Product to a Black Series retailer or Black Series service provider location offering carry-in service. Service will be performed at the location.
- (ii) Main-in service. If Black Series determines that your Black Series Product is eligible for mail-in service, Black Series will send you a prepaid label so that you may ship your Black Series Product to a Black Series service provider. Instructions may be sent to you via email or in hard copy.
- (iii) Do-it-yourself (DIY) part service. DIY parts service allows you to service your own Black Series Product. The following process may apply.
 - (a) Service where Black Series does not require return of the replaced Black Series Product or part. Black Series will ship you free of charge a replacement Black Series Product or part accompanied by instructions on installation.
 - (b) Black Series is not responsible for any labor costs you incur relating to DIY parts service.

© 2021 Black Series LLC. All rights reserved. Black Series logo are trademarks of Black Series LLC, registered in the U.S. and other countries.

20210113-Warranty-Document-US-v1.0